



LOAD





LIFT



LEAVE

When aligning to platform, take note of this piece.



To roll the lift on its wheels:

- 1- Lower lift all the way down.
The wheels will lift the unit.
- 2- RELEASE brakes by pulling cable.